
DJI MIC MINI

User Manual

v1.0 2024.11



This document is copyrighted by DJI with all rights reserved. Unless otherwise authorized by DJI, you are not eligible to use or allow others to use the document or any part of the document by reproducing, transferring, or selling the document. Users should only refer to this document and the content thereof as instructions to operate DJI products. The document should not be used for other purposes.

Searching for Keywords

Search for keywords such as Battery or Install to find a topic. If you are using Adobe Acrobat Reader to read this document, press Ctrl+F on Windows or Command+F on Mac to begin a search.

Navigating to a Topic

View a complete list of topics in the table of contents. Click on a topic to navigate to that section.

Printing this Document

This document supports high resolution printing.

 © 2024 DJI All Rights Reserved.

Using this Manual

Legend

⚠ Important Hints and Tips Reference

Read Before Use

DJI™ provides you with tutorial videos and the following documents:

1. *Safety Guidelines*
2. *Quick Start Guide*
3. *User Manual*

It is recommended to watch all the tutorial videos and read the *Safety Guidelines* before using for the first time. Make sure to review the *Quick Start Guide* before using for the first time and refer to this *User Manual* for more information.

© 2024 DJI All Rights Reserved.

Contents

Using this Manual 3

Legend 3

Read Before Use 3

1 Product Profile 5

1.1 Transmitter 5

1.2 Receiver 6

1.3 Charging Case 8

2 Using the Product 10

2.1 Charging 10

Charging with the Charging Case 10

Charging with the Charging Dock 10

2.2 Installing the Windscreen 11

2.3 Wearing the Transmitter 11

2.4 Linking the Transmitter and Receiver 12

Linking via the Charging Case 12

Linking Manually 12

2.5 Using with a Phone 12

2.6 Using with a Camera 13

2.7 Using with a Computer 14

2.8 Transmitter Directly Connected to Filming Devices 14

Connecting to a Phone 14

Connecting to DJI Filming Devices 15

3 Firmware Update and Parameter Adjustment 16

3.1 Connecting to the DJI Mimo App 16

Connecting via the Adapter 16

Connecting via Bluetooth 16

3.2 Updating Firmware 17

3.3 Adjusting Parameters 17

4 Appendix 18


4.1 Specifications 18


4.2 Aftersales Information 18

© 2024 DJI All Rights Reserved.

1 Product Profile

1.1 Transmitter





1. **System Status LED**

Battery Level		
—	Solid red	0-10%
—	Solid green/blue*	> 10%
Link Status with the Receiver		
—	Solid green	Linked with the receiver
·····	Blinks green slowly	Not linked with the receiver
·····	Blinks blue and green alternately	Linking
Bluetooth Link Status		
—	Solid blue	Linked with a Bluetooth device
·····	Blinks blue slowly	No Bluetooth device linked
·····	Blinks blue and green alternately	Linking
Battery Level During Charging*		
·····	Blinks green/blue slowly	0-25%
× 2 ·····	Blinks green/blue twice	26-50%
× 3 ·····	Blinks green/blue three times	51-75%
× 4 ·····	Blinks green/blue four times	76-100%
◎	Off	Fully charged
Firmware Update		

© 2024 DJI All Rights Reserved.

—	Solid yellow	Firmware updating

* The color of the light depends on the working mode. Take the green light as an example.

2. **Linking Button**

   Press and hold for two seconds to start linking. After connecting the microphone to DJI filming device, press to start or stop recording videos.

3. **Power Button**


   Press and hold for two seconds to power on or off. Press to enable or disable noise cancelling.

4. **Noise Cancellation LED**

   Solid yellow: Noise cancelling enabled

   LED off: Noise cancelling disabled

1.2 Receiver



1. **Power Button**

   Press and hold for two seconds to power on or off.

2. **Dial**

   Rotate to adjust the gain of the receiver.

3. **Transmitter Status LED**

Battery Level		
—	Solid red	0-10%
—	Solid green	> 10%
Status		

© 2024 DJI All Rights Reserved.

◎	Off	Not linked with the receiver
·····	Blinks green quickly	Linking
—	Solid yellow	Noise cancelling enabled

4. **Receiver Status LED**

Battery Level		
—	Solid red	0-10%
Channel		
—	Solid green	Mono/Safety Track
—	Solid cyan	Stereo
·····	Blinks green/cyan slowly*	No audio recording device linked
Bluetooth Link Status		
—	Solid blue	Linked with a Bluetooth device
·····	Blinks blue slowly	No Bluetooth device linked
Battery Level During Charging**		
·····	Blinks green/blue slowly	0-25%
× 2 ·····	Blinks green/blue twice	26-50%
× 3 ·····	Blinks green/blue three times	51-75%
× 4 ·····	Blinks green/blue four times	76-100%
◎	Off	Fully charged
Firmware Update		
—	Solid yellow	Firmware updating

* The color of the light depends on the current channel used. Take the green light as an example.

** The color of the light depends on the working mode. Take the green light as an example.

5. **3.5mm Audio Output Jack**

   For audio output to a camera.

6. **Linking Button**

   Press and hold for two seconds to start linking. Press twice to switch between Mono and Stereo.


7. **Expansion Port**

   Used for connecting to the phone adapter.

© 2024 DJI All Rights Reserved.

8. **Data Port (USB-C)**
9. **Clip**

1.3 Charging Case



1. **Battery Level LEDs**

   LED is on

   LED is blinking

   LED is off

Battery Level During Charging (LEDs Blink in Sequence)	
	76%-99%
	51%-75%
	26%-50%
	≤25%
	Fully charged
Battery Level	
	76%-100%
	51%-75%
	26%-50%
	10%-25%
	< 10%

© 2024 DJI All Rights Reserved.

2. **Charging Port (USB-C)**

- Fully charge the battery at least once every three months to maintain battery health. If the battery is not used for an extended period, battery performance maybe affected or may even cause permanent battery damage.


© 2024 DJI All Rights Reserved.

2 Using the Product

2.1 Charging


Charging with the Charging Case


Place the transmitters and the receiver in the charging case to start charging simultaneously. If the charging case runs out of power, use the provided USB-C cable to charge the case. The transmitter and receiver will automatically power on once removed from the charging case.



Charging with the Charging Dock

If the combo purchased does not include a charging case, attach the transmitter to the charging dock and use the provided charging cable to charge the transmitter and receiver.






 © 2024 DJI All Rights Reserved.


2.2 Installing the Windscreen

In outdoor or windy environments, use the windscreen to reduce wind noise and improve audio quality.



2.3 Wearing the Transmitter

The transmitter can be attached to clothing using the clip or magnet, or can be placed on a stable surface using the magnet.



© 2024 DJI All Rights Reserved.

2.4 Linking the Transmitter and Receiver


Before first use, refer to Updating Firmware to update the device to the latest firmware version. The transmitter and receiver in the combos are linked by default. Follow the steps below to link the transmitter and receiver if they become unlinked.

Linking via the Charging Case

Place the transmitters and the receiver in the charging case to link them automatically.

Linking Manually

1. Press and hold the linking button on the transmitter for two seconds until the system status LED blinks blue and green alternately.
2. Press and hold the linking button on the receiver for two seconds until the transmitter status LED on the front of the receiver blinks green rapidly, indicating that the device is in linking status. The status LEDs will turn solid green after successful linking.




2.5 Using with a Phone

Install the receiver (RX) to the phone using the adapter, then clip or magnetically attach the transmitter (TX) to the collar. The transmitter can then capture audio for the phone.

- Press the linking button on the transmitter to start and stop recording.
- For extended filming or live streaming, it is recommended to use the adapter to attach the receiver to the phone. After installation, when using the charging cable to charge the receiver, the phone can be charged simultaneously.
- The Lightning adapter is sold separately.

© 2024 DJI All Rights Reserved.



2.6 Using with a Camera

Mount the receiver to the camera using the clip and connect the audio cable. The transmitter will then capture audio for the camera.


- After installation and connection, visit https://www.dji.com/mic-mini/downloads and refer to the Instructions on Recommended Gain for Camera Setup to reduce the camera gain in order to prevent audio clipping.
- After adjusting the camera gain, it is recommended to increase the gain of the receiver for better audio quality.



© 2024 DJI All Rights Reserved.


2.7 Using with a Computer

Connect the receiver to the computer using the provided charging cable or adapter, and set the audio input options on the computer. The transmitter can then be used as an external microphone.



2.8 Transmitter Directly Connected to Filming Devices

The transmitter can connect to phones or DJI filming devices via Bluetooth.



Connecting to a Phone

1. When the transmitter is powered on, press and hold the linking button on the transmitter for two seconds until the system status LED blinks blue and green alternately.

© 2024 DJI All Rights Reserved.

2. Enable Bluetooth on the phone and select DJI Mic Mini-XXXXXX among the searched Bluetooth devices to connect. Connection is successful when the status LED on the transmitter is in solid blue.

The transmitter will then function as an audio input device and can be used with third-party recording or live streaming applications.

Connecting to DJI Filming Devices

Enter the system settings interface of your DJI filming device. Tap **Wireless Microphone** and follow the on-screen instructions to complete the connection. Connection is successful when the status LED on the transmitter is on solid blue.

Press the linking button on the transmitter to start and stop recording on the filming device. Tap **Wireless Microphone** to configure audio-related settings for the transmitter.


© 2024 DJI All Rights Reserved.

3 Firmware Update and Parameter Adjustment

After connecting the microphone to the DJI Mimo app, you can update the firmware or adjust parameter settings using your phone.

3.1 Connecting to the DJI Mimo App

Connecting via the Adapter



- Make sure that the transmitter and receiver are linked.

Connecting via Bluetooth

Connecting the Transmitter

1. Refer to Connecting to a Phone to connect the transmitter to a phone via Bluetooth.
2. Open the DJI Mimo app to automatically search for nearby available devices. Tap to connect once the transmitter is discovered. After successful connection, the app will automatically enter the device settings interface.

Connecting the Receiver

 © 2024 DJI All Rights Reserved.

1. When the receiver is powered off, press and hold the power button for six seconds. The system status LED on the receiver will blink green and then blink blue slowly, indicating that the receiver is ready to be connected.
2. Open the DJI Mimo app to automatically search for nearby available devices. Tap to connect once the receiver is discovered. After successful connection, the app will automatically enter the device settings interface.

3.2 Updating Firmware

Tap **About Devices** on the device setting interface of the DJI Mimo app to view the device name, SN code, and firmware version. Tap the firmware version to download and install the latest version.

- When updating the firmware on an iOS device, disconnect the adapter and then connect the transmitter and receiver to the DJI Mimo app via Bluetooth separately.

3.3 Adjusting Parameters

In the device settings interface of the DJI Mimo app, you can view connected devices and their battery status or adjust parameters.

- When the transmitter status LED is disabled, press any button can turn it on.

© 2024 DJI All Rights Reserved.

4 Appendix

4.1 Specifications

Visit the following website for specifications.

https://www.dji.com/mic-mini/specs

4.2 Aftersales Information

Visit https://www.dji.com/support to learn more about aftersales service policies, repair services, and support.

© 2024 DJI All Rights Reserved.

WE ARE HERE FOR YOU

Contact

DJI SUPPORT

This content is subject to change without prior notice.

https://www.dji.com/mic-mini/downloads

If you have any questions about this document, please contact DJI by sending a message to DocSupport@dji.com.

DJI is a trademark of DJI.
Copyright © 2024 DJI All Rights Reserved.